

VOIPC series

Quick Guide



Read and understand thoroughly this safety awareness & instruction before using and keep it for future reference .

1 Packing list

Please confirm the network camera is intact when open the package (hereinafter referred to as the "camera"), also check the accessory list items are completed, if you find anything missing, please contact with dealers.

2 Interface

You can check if the camera is under normal operation according to the below indication.





Description

Explain

	Explain		
	On	Flicking	Off
Double color light (Blue)	Networking	Monitoring	No network
Double color light (Pink)	Detect TF card	Recording	Don't detect TF card

3 Download APP

1、 If you use the mobile phone client

Scanning the QR code on the packaging box, download and install according to the prompts to complete the registration (IOS user can download from APP Store, Search and download "Yoosee".Android user can access to website: www.yoosee.co to download APP.



2、 If you use the PC client

Turn on the computer, Enter "www.yoosee.co" in the browser, download "CMS", according to the prompt set the user-name and password, and add the camera. The default user name : admin password: 123.

You can manually enter the 3C ID and password to add the camera. 3C ID at the bottom of the camera or on the packaging box, its 7 Arabia digitals, and the default password is 123.

4 Add Device

When you get the device , please Reset it before adding to the App . (Press the reset button about 5 seconds until hear the “bing” voice from the camera .)

By WiFi

Connect the mobile with the wireless router(Pls confirm the mobile is connecting with the 2.4G WIFI,as the camera WIFI not support 5G network yet)

Then Access to APP “Yoosee” on your mobile, click the “+” at the top right corner, select “ Smartlink” , camera APP will automatically recognize the WiFi SSID which mobile connected with. Input the WiFi password ,click “ next” ,follow the instruction to Connect camera with WiFi ,Then input the camera device password to finish the Device Adding step



By Manual

Once powered on the camera, connect the NET interface on the camera with the net interface of router (Make sure open the DHCP function of the Router). The NET indicator will be on once network connection done. Then open the APP “Yoosee”, click the “+” at the top right corner, select “ Manual Add” ,then input the device ID, name,password to finish the Device Adding step



5 Visit Device

Open the APP, Click the device icon in the left side of Device list, to access to camera monitoring screen. Click the device name in the Device list, "playback /Settings/ Edit" menu will pop up, click the "playback "on the menu, it will play back the video in the TF card, click the " Settings", to set the camera Device functions and parameters as Below.



1. Defence Area setting : Camera(some model support this function) need

self-learning (coding) to match the wireless sensor (door magnet, smoke detector,PIR etc.) with the same frequency(433M) to set up the wireless alarm system..Eg. Set the Door magnet in the channel 1 of defence area – Hall : Click the name of the Device on the mobile APP. "playback /Settings/ Edit" Menu will pop up, then enter the submenu step by step " Setting"/"Defense Area" /"Hall"/"1", select "1". meanwhile trigger the door magnet . then click ok to trigger the wireless sensor to code .,then it will show "operation successful " ,otherwise, it will show " operation failed". After coding successful. Back to menu of "Setting" ,access to " Alarm Settings". On the " Receive alarm message "icon. Then arm the alarm for the camera. Once the door magnet has

been triggered, camera will send alarm to the Mobile APP.

2 .Clear coding : access to the Defense Area ,select the Channel which need

clear the coding .Just Click the red icon on the right side and confirm to clear the coding

3、 Alarm Setting :

Arming the alarm: There are two methods to arm the alarm.1: press the Coded IR learning remote controller (the lock button) to arm the alarm. 2: Click the Lock icon on the right side of Device name on the mobile APP (Yoosee). After arming the alarm, the camera will send the alarm signal to APP once any alarm triggered. Meanwhile,send the captured picture to the alarm push email address.

Set the Alarm push ID/Alarm push Email : Click the Device name on the APP, "playback /Settings/ Edit" menu will pop up, then access to the submenu " setting/Alarm setting". Then on the "Receive alarm message " .And input the email address to receive the alarm message on the " alarm push Email"

Motion Detection: Same step as above to set alarm. Just need On the "Motion Detection". Then the camera will send alarm message once any motion or change in the monitoring location.

PIR: Same step as above .Just need on PIR, camera will send alarm message once the camera PIR detect the infrared from any person or animal (only some model support this feature)

Buzz : Same step as above .Just need on the Buzz. The camera will start Buzzing till disarm the alarm manually .

4、 Device update

Click the Device name on the APP, "playback /Settings/ Edit" menu will pop up, then access to submenu "setting/device update". It will show the latest version and confirm if you need update the device version

5、 Factory setting reset

Reset will clear all the setting: include WIFI ,password, alarm setting, Defense area setting etc. Operation as below: there is one RESET button (hole)on the bottom of the camera. Just need use one Needle shape tool insert into the RESET hole ,press the RESET button inside. After hear the sound of "Di-",press another 3 seconds till heard one sound "PIU..." . All the indicators turn on ,means the camera RESET successful .

Q: Add camera Device by WiFi, But APP didn't discover any new device .

A: Please confirm that the mobile phone and camera connected in the same LAN (one router), check if the Network indicator of the camera is ON. If the camera and mobile is not in the same LAN, Pls try to add device by Manual add

Q: Indicate “ wrong password” ,when try to access to camera monitoring status on APP

A: Pls check if the remote monitoring password has been input correctly when adding the camera device into APP. If it's not correct, then need click device name to popup the menu “ Playback/Setting/Edit” ,access to “Edit” to input the right password. if you forgot the password, then RESET camera to recover to Factory Defaulting.

Q: In the Device list ,Device Indicate “ Offline”

A: Pls check if the camera is connecting the network. Check if the indicator is on. Make sure the router is working well

Q: While Playback recording,can't find the recording file

A: First check if the TF card is defective.if it is fine. Then pls check the search time for the recording file. Also Make sure the camera system time has not been changed by mistake.

Q: Can't do any recording ;Or Can't overwrite the data automatically when TF card is full

A: Format the TF card on the computer first, and then insert the TF card into the camera, if the blue light is not ON, TF card is defective, please replace the TF card.

Q: WIFI Camera can't connect with WiFi

A: make sure the WiFi password is correct. Camera doesn't support 5G, so pls make sure the mobile connect with 2.4G WIFI network

Q: Forget the password?

A: There is a reset hole at the bottom of the camera, use a needle shape tool insert into the reset hole, restore the default password "123".

Q: **Can't set WIFI**

A: pls check if the camera has the sound "DiDi" when power on the camera, if no ,then RESET the camera

Q: **Can't record with TF card**

A: Pls make sure to format the TF card via the OSD menu step "Setting/Storage settings" before recording

Q: **After Format the TF card, it still can't do recording or can't indicate the TF card capacity**

A: Pls check if Allocation unit size is less than 16kb while format the TF card on computer.pls make sure the correct parameter should be above 16KB